



# **USER'S MANUAL**

No.9921 碎纸机使用说明书

MODEL:S220LPS3-1



使用时注意事项 .....	1
产品规格 .....	2
装箱清单 .....	2
产品外形结构及名称 .....	3
使用说明 .....	3
保养方法 .....	4
常见故障分析及排除 .....	4
<b>Useage attention</b> .....	<b>5</b>
<b>Product Specifications</b> .....	<b>6</b>
<b>Packing List</b> .....	<b>6</b>
<b>Product Outlook &amp; Names</b> .....	<b>7</b>
<b>Operating Procedures</b> .....	<b>7</b>
<b>Maintenance</b> .....	<b>8</b>
<b>Trouble Analysis &amp; Troubleshooting</b> .....	<b>8</b>



危險，  
和

手解鎖後  
刀，以免

危險，  
和

手解鎖後  
刀，以免

危險，  
和

手解鎖後  
刀，以免

危險，  
和

手解鎖後  
刀，以免


危險，  
和

## 产品外形结构及名称

拉 手

使用说明


保





**Product Specifi**





# Maintenance

## Trouble Analysis & Troubleshooting

TROUBLE	TROUBLE ANALYSIS	TROUBLESHOOTING
SHREDDER NO RUNNING		
CONSTANTLY RUNNING		
NOISE LOUD		

In case the above solutions are not able to remove any trouble of the shredder, please stop using it immediately, disconnect the power plug and switch off power supply. Contact the local service agency of our company.

得力集团有限公司  
DELI GROUP CO., LTD.

地址：浙江 宁海县黄坛镇车站西路128号

Add: No.128, Bus Stop West Road, Huangtan

Town, Ninghai County, Zhejiang

电话(Tel): 0574-65278888

传真(Fax): 0574-65273660

执行标准

[www.deli-stationery.com](http://www.deli-stationery.com)